


M-6639 Instruction Manual



Danger

Misuse could easily result in a serious accident or death

- Do not use with household gas tables or cassette contraptions. The stove may malfunction or be damaged, or the gas respirator or fuel tank may heat up, causing an explosion or fire.
- Do not use in poorly ventilated areas, such as inside a tent.
- Use the product in a stable condition, taking care not to tilt or drop it.
- Do not use gasoline, kerosene or other fuels as igniters.
- Do not use on a heat sensitive object or place combustible or flammable materials around it while in use.
- Do not shake or swing the product around.
- Do not transfer coals by turning the body upside down.
- Do not leave the area while in use.



SAFETY FIRST

Sharp Edges
Watch Your
Fingers



Warning

Misuse could result in injury to the user and/or damage to property

- Do not use for any purpose other than making a charcoal fire.
- The body and handle will be very hot during and after use, so please handle with care.
- Use gloves or mittens when in use.
- Do not apply excessive force or impact.
- Do not put your finger in the ignition port.
- Be careful of sparks during use.
- Do not modify or alter the product.
- Be careful not to injure yourself by the body, handle end, or ignition port.
- Do not pour water on the product or allow it to cool down quickly, or you may be injured.